



NO.	PART NO.		Q'TY / UNIT	PARTS NAME
1	KPNT1	001	6	PUSH NUT
2	PMRAC-30MH1	905	1	TOP COVER
3	PMRAC-25NH4	S09	1	OVERHEAT THERMISTOR SUPPORT
4	PMRAC-63CA1	S02	1	TERMINAL BOARD (2P)
5	PMRAC-70YHA	908	1	SIDE PLATE L
6	PMRAC-70YHA	916	1	NET COVER
7	PMRAC-70NPD	S05	1	D-GRILL
8	PMRAC-70YHA	S07	1	PROPELLER FAN
9	PMRAC-70YHA	S12	1	SUPPORT (FAN MOTOR)
10	PMRAC-70YHA	S13	1	THERMISTOR (DEFROST)
11	PMRAC-VX13CET	S04	3	TERMINAL BOARD (3P)
12	PMRAC-X13CX	902	3	VALVE (2S)
13	PMRAM-33NP2E	S05	1	REACTOR
14	PMRAM-33NP2B	S06	1	COIL (REVERSING VALVE)
15	PMRAM-33NP2B	S07	1	REVERSING VALVE
16	PMRAM-33NP2E	S08	3	EXPANSION VALVE
17	PMRAM-53NP2B	S08	1	EXPANSION VALVE COIL (W)
18	PMRAM-53NP2B	S09	1	EXPANSION VALVE COIL (R)
19	PMRAM-53NP2B	S10	1	FAN MOTOR
20	PMRAM-65QH4	S10	1	THERMISTOR (OUTSIDE TEMPERATURE)
21	PMRAM-53NP3E	S08	1	STRAINER (CO-PIPE-AS 1)
22	PMRAC-70NPD	S04	1	CABINET
23	PMRAM-53NP3E	S01	1	P.W.B. (MAIN)
24	PMRAM-53NP3E	S02	1	P.W.B. (INVERTER)
25	PMRAM-68NP3B	S03	1	EXPANSION VALVE COIL (B)
26	PMRAM-53NP3E	S04	1	THERMISTOR-V-W
27	PMRAM-53NP3E	S05	1	THERMISTOR-V-N
28	PMRAM-53NP3E	S03	1	COMPRESSOR
29	PMRAC-72Q8	S03	1	THERMISTOR (OH)
30	PMRAM-72QH5	910	1	STRAINER (ST-PIPE-AS 2)
31	PMRAM-53NP3E	S06	1	STRAINER (ST-PIPE-AS 3)
32	PMRAM-53NP3E	S07	1	STRAINER (ST-PIPE-AS 4)
33	PMRAM-72QH5	913	1	SV-COVER
34	PMRAC-70NPD	S02	1	CONDENSER
35	PMRAM-72QH5	S14	1	SIDE PLATE R
36	PMRAM-72QH5	S20	1	SUPPORT (DEF-THERMISTOR)
37	PMSMARTY235M	902	1	VALVE 3S
38	RAC-2226H	805	3	COMPRESSOR RUBBER